

Directions

The Stor-All has three (3) lids located on top of the box. If center of seat back is stationary, but passenger and driver seat fold down (bucket seats) the left and right lids can be used for storage and to access middle of box. If entire back seat folds down (bench seat) all three (3) lids can be opened. Four (4) pre-drilled holes—two on rear wall and two on bottom of unit—are provided for easy behind seat or trunk installation. Self-tapping 1" screws (not provided) are needed for either installation. See diagrams below.



BENCH SEAT



BUCKET SEATS

